The imagination driving Australia's ICT future.

NATIONAL ICT AUSTRALIA LIMITED

Power Management and Dynamic Voltage Scaling: Myths and Facts

David Snowdon, Sergio Ruocco, and Gernot Heiser

david.snowdon@nicta.com.au

sergio.ruocco@nicta.com.au

gernot.heiser@nicta.com.au

Australian Government

Department of Communications, Information Technology and the Arts

Australian Research Council

NICTA Members

THE AUSTRALIAN NATIONAL UNIVERSITY

UNSW

Department of State and Regional Development

NSW First for Business

BusinessACT ACT GOVERNMENT

Victoria The Place To Be

The University of Melbourne

The University of Sydney

Queensland Government

Griffith University

QUT Queensland University of Technology

The University of Queensland Australia

NICTA Partners

Introduction

Dynamic Voltage Scaling

- used for power management
- often based on naïve system power models

Introduction

Dynamic Voltage Scaling

- used for power management
- often based on naïve system power models

Claim: naïve models lead to wrong results

INTRODUCTION

Dynamic Voltage Scaling

- used for power management
- often based on naïve system power models

Claim: naïve models lead to wrong results

Analysis

- real measurements
- 14 macro-benchmarks
- run on real hardware (not simulators)

INTRODUCTION

Dynamic Voltage Scaling

- used for power management
- often based on naïve system power models

Claim: naïve models lead to wrong results

Analysis

- real measurements
- 14 macro-benchmarks
- run on real hardware (not simulators)

Results

- real measurements differ dramatically from naïve models
- optimum dependent on workload

Naïve Power Model

Basis *dynamic* switching power P of CMOS circuits:

$$P \propto fV^2$$

NAÏVE POWER MODEL

Basis *dynamic* switching power P of CMOS circuits:

$$P \propto fV^2$$

Assumption: # cycles for computation is independent of f_{core}

$$E \propto V^2$$



NAÏVE POWER MODEL

Limitations of the naïve power model:

➜ ignores static power

➜ ignores other components: memory and busses

- they affect execution time, consume energy
- their energy consumption scales differently than CPU



Hardware Platform

PLEB 2:

- ➜ Single board computer based on Intel XScale (PXA255)
- ➜ Representative of a typical embedded system



HARDWARE PLATFORM

- Three power supplies: CPU, Memory and IO
- Each power supply's current is measured
- On-board micro-controller (AVR) for monitoring
- Samples taken periodically according to AVR clock
- $f_{\max}$ samples is 15 KHz, subdivided into three channels



BENCHMARKS AND V/F CONFIGURATIONS

14 Macro-benchmarks:

- ➜ most from MiBench, selected according to resource limitations
- ➜ automotive, industrial control, network, office, signal processing
- ➜ plus 4 more: gzip, MP3, image analysis, speech compression

BENCHMARKS AND V/F CONFIGURATIONS

14 Macro-benchmarks:

- ➜ most from MiBench, selected according to resource limitations
- ➜ automotive, industrial control, network, office, signal processing
- ➜ plus 4 more: gzip, MP3, image analysis, speech compression

Valid voltage/frequency configurations for ARM XScale:

V_{core} (V)	f_{cpu} (MHz)	$f_{internalbus}$ (MHz)	f_{mem} (MHz)
1.0	100	50	100
1.0	200	100	100
1.1	300	100	100
1.3	400	100	100
1.3	400	200	100

1. Normalized CPU Energy Model



1. Normalized CPU Energy



1.B Normalized Memory Energy



2. Memory Power



2. Memory Power vs CPU Power



3. Normalized Total Energy



3. Normalized Total Energy vs Naïve Model



Padding with idle power to equal total time



Padding with idle power to equal total time



Padding with idle power to equal total time



4. Normalised total energy padded to equal time



Memory Power Estimation

What if we cannot measure memory power ?

Memory Power Estimation

What if we cannot measure memory power ?

Model memory power via performance counters.

Memory Power Estimation

What if we cannot measure memory power ?

Model memory power via performance counters.

- counting memory accesses leads to good results

  Weissel and Bellosa, "Process Cruise Control... ", CASES'02

- not enough performance counters on XScale

Memory Power Estimation

What if we cannot measure memory power ?

Model memory power via performance counters.

- counting memory accesses leads to good results

  Weissel and Bellosa, "Process Cruise Control... ", CASES'02

- not enough performance counters on XScale

Cache misses can predict memory accesses ?

Memory Power Estimation

What if we cannot measure memory power ?

Model memory power via performance counters.

- counting memory accesses leads to good results

  Weissel and Bellosa, "Process Cruise Control... ", CASES'02

- not enough performance counters on XScale

Cache misses can predict memory accesses ?

Investigated via two micro-benchmarks

- *read*: only load instructions
- *modify*: load and then store to same location

5. Memory power vs cache miss rate



5. Memory power vs cache miss rate



Conclusions and Future Work

Conclusions and Future Work

➜ Simple models do not work

Conclusions and Future Work

➜ Simple models do not work

- static power contributes significantly to energy consumption
- also memory power is important (may even dominate)

Ignoring these distorts reality leading to massive mispredictions

Conclusions and Future Work

- ➜ Simple models do not work
  - static power contributes significantly to energy consumption
  - also memory power is important (may even dominate)

  Ignoring these distorts reality leading to massive mispredictions
- ➜ Best operating points depend on application workload

Conclusions and Future Work

➜ Simple models do not work

- static power contributes significantly to energy consumption
- also memory power is important (may even dominate)

Ignoring these distorts reality leading to massive mispredictions

➜ Best operating points depend on application workload

- direct observation is required

Conclusions and Future Work

- ➜ Simple models do not work
  - static power contributes significantly to energy consumption
  - also memory power is important (may even dominate)

  Ignoring these distorts reality leading to massive mispredictions
- ➜ Best operating points depend on application workload
  - direct observation is required

Future Work

Mechanism and policies for real-time power management